

BOSE X Helmet Conversion Guide

Dear Customer,

Thank you for your purchase. Sky Cowboy Supply Company is excited about this product and being able to provide safe, cost effective safety gear to backcountry pilots. Buying a helmet should not be a compromise between safety and cost. Backcountry flying is one of the most freeing experiences there is. While this type of flying has added risk in its operation, accidents tend to be survivable due to the low speeds in which they occur. Wearing a helmet may make all the difference. Backcountry pilots make a small and intimate community and cannot afford to become any smaller. Please encourage your fellow pilots to wear a helmet when flying whether that is through this product or another.

Tailwinds,

Instructions:

1. Pull out the little "U Clips." Needle nose pliers do the trick here.
2. Remove the stock Bose "Stirrups" by removing the retaining screws.
3. Line up the new stirrup adaptors with the Bose X screw post and rotate until vertical. Adaptor has a built-in lip that will lock into place. Re-install retaining screws.
4. Remove the stock Bose "stirrups" by removing the retaining screws.
5. Next, clip on the Peltor ear muff holders, on. **These attach at 90 degrees**, then turn to normal orientation. Needle nose with a quick squeeze work well here.
6. Time to route everything through the helmet to hide the wire. Under the padding on the side and top of the helmet. Very easy to do.

