


The "Eliminator" Inline Undercoat and Decal Remover

Blue Ringed Tool Parts Breakdown



Part Number	Drawing ID	Description
30501	1	Valve Screw
30502	2	O-Ring
30503	3	O-Ring
30504	4	Air Regulator
30505	5	Valve Spring
30506	6	O-Ring
30507	7	Valve Stem
30510	10	Lever Pin
30511	11	Exhaust Sleeve
30512	12	O-Ring
30513	13	Retainer Ring
30514	8,14	Air Motor Housing
30515	15	Ball Bearing
30516	16	Rear End Plate
30517	17	Cylinder Pin
30518	18	Rotor Blade
30519	19	Rotor
30520	20	Cylinder
30522	22	Ball Bearing
30523	23	Ball Bearing
30526	26	Ball Bearing
30527	27	Needle Roller
30528	28	Idle Gear
30529	29	Idle Gear Pin

Part Number	Drawing ID	Description
30533	33	Nut
30534	34	Roll Pin
30536	36	Ball Bearing
30545	44,45	Screw
30550	50	Grip
30553	53,73	Tapping Screw
30554	54	Arrow Sign Label
30555	55	Caution Label
30565	65	Planet Cage
30566	66	Housing Cap
30568	68	Key (Round Tip)
30569	69	Key (Square Tip)
30571	71	Throttle Lever
30574	74	Front End Plate
30575	75	Internal Gear
30576	76,77	Bevel Gear Set
30579	79	Toothed Belt
30580	80,81,54	Plastic Housing Set
30582	82	Plastic Label
30583	83	Spacer
30595	42,48,63,67,70,72,78	Drive Shaft Sub Assembly
30596	37,38,41,42,78	Spindle Sub Assembly