

Transmitter/Receiver Matching

To match the transmitter to the receiver console:

- Shut off power
- Hold the learn button
 - Swing Auger Mover – Left
 - Electric Auger Mover – Left Forward
 - Trailer Chute Opener – Chute 1 Open
 - Endgate and Hoist – Endgate Up
 - Multi-Channel System – Endgate Up
- Turn power on while still holding the learn button; the receiver light learn light should come on
- Release learn button
- Press any button on remote to have the receiver learn that remote

Your receiver can learn up to 8 remotes. If you add a ninth remote, the first one will be erased.