

SPARE PARTS FOR BLASTING MACHINES



PNEUMATIC VALVE FOR
AIR INLET **MVNC**

PNEUMATIC VALVE FOR AIR INLET

401-121	Valve MV	1" NC
401-122	Valve MV	1" 1/4 NC
401-124	Valve MV	2" NC

401-125	Valve MV	1" NA
401-126	Valve MV	1" 1/4 NA
401-128	Valve MV	2" NA



PNEUMATIC VALVE FOR
AIR INLET **MVNA**

MANUAL VALVE FOR ABRASIVE ADJUSTMENT

401-102	Abrasive Valve	3/4"
401-103	Abrasive Valve	1"
401-104	Abrasive Valve	1" 1/4



MANUAL VALVE FOR ABRASIVE
ADJUSTMENT WITH LEVER

PNEUMATIC VALVE FOR ABRASIVE ADJUSTMENT

401-161	MVRA Valve	1"
401-170	MVRA Valve	1" 1/4
401-173	MVRA Valve	2"



PNEUMATIC VALVE FOR
ABRASIVE ADJUSTMENT

MEMBRANE EXHAUSTING VALVE

401-171	Brass exhausting valve	1"
401-168	Valve body in brass	1"
401-137	Steel exhausting valve	1"
401-167	Valve body in steel	1"
401-166	Membrane for exhaust valve	



BRASS EXHAUSTING VALVE

Y FITTINGS

400-045	—	3/4"
400-046	—	1"
400-047	—	1" 1/4




Y FITTINGS

SPARE PARTS FOR PNEUMATIC VALVES TYPE MV

GASKETS KIT

401-237	Ø	1"
401-238	Ø	1" 1/4
401-239	Ø	2"



GASKETS KIT FOR MV VALVE

MEMBRANES

401-234	Ø	1"
401-235	Ø	1" 1/4
401-236	Ø	2"



MEMBRANES FOR MV VALVE

SAFETY VALVE

401-106	4 Bar (tested)
401-107	8 Bar (tested)
400-126	12 Bar (tested)



SAFETY VALVE

HAND LEVER WITH HOSE FOR REMOTE CONTROL

401-150	length m	6
401-151	length m	12
401-152	length m	22
401-153	length m	32
401-154	length m	42



HAND LEVER
WITH HOSE



COPERCHIO

COVER FOR SANDBLASTING MACHINE

207-001	capacity	80 – 120 L
207-002	capacity	200-230-300 L



SETACCIO

SIEVE FOR SANDBLASTING MACHINE

207-010	capacity	25 L
207-011	capacity	80 – 120 L
207-012	capacity	200 – 230 – 300 L

ABRASIVE MIXING GROUP FOR STANDARD MACHINE

401-196	VSM-VSA 24
401-197	VSM-VSA 80-120
401-198	VSM-VSA 200-230-300



ABRASIVE MIXING GROUP

ABRASIVE MIXING GROUP FOR MACHINE USED IN PLANTS

401-211	Mixing Group	1"
401-212	Mixing Group	1" 1/4



MIXING GROUP FOR
MACHINE USED IN PLANT