






Rivet Size Guide 	PR-SPR-56: Self-Piercing Rivet  5mm(w) x 6mm(h)	PR-SPR-58: Self-Piercing Rivet  5mm(w) x 8mm(h)	PR-SPR-510H: Self-Piercing Rivet  5mm(w) x 10mm(h)
--	--	---	---

For Self-Piercing Rivets



Flow Form Die



For Removing Rivets



For Flattening



For Calibration Punch



2.4 Functionality

- Electro-hydraulic operation, portable and easy to operate.
- Different sized arms are available for various applications.
- Arms rotate 360° for use at various angles.
- The output pressure can be adjusted for different repair applications.
- Micro-computer control system - Pressure is monitored automatically and has a double safeguard function, automatically retracting after the rivet has been compressed.
- Manual Reset - Operation can be stopped by pressing the manual reset button. The forward motion of the ram will stop and will automatically retract to the original position.